







IMPORTANT SOFTWARE UPDATE INFORMATION

PLEASE READ BEFORE USE

KEEP YOUR JYKER PRODUCT UP TO DATE

Important Software & Support Information

Your JYKER product may periodically receive software updates designed to improve:

-  Display performance
-  Remote control responsiveness
-  Stability & functionality
-  Overall user experience



HOW TO DOWNLOAD AND INSTALL THE LATEST SOFTWARE



1. Visit:
<https://jykerusa.com/pages/product-download>



2. Search for your item model number
Example: JAMP79



3. Download the latest software update from the [Download Essentials](#) section directly onto a USB 2.0 flash drive



4. The software file must be placed directly onto the USB drive and **NOT** inside any folder



5. Insert the USB stick into the device and power the unit on



6. The update should begin automatically and complete within approximately **1 minute or less**



7. Once the screen shuts off and then turns back on, the update has completed **successfully**



 **Thank you for choosing JYKER.** 



PREMIUM AUDIO



SMART PERFORMANCE



MODERN INNOVATION